



001 125310-5 SPEED CHANGE LEVER ASS'Y 1 PC.
001 C10 231433-0 COMPRESSION SPRING 4 2 PC.
001A 125310-5 SPEED CHANGE LEVER ASS'Y 1 PC.
001A C10 231433-0 COMPRESSION SPRING 4 2 PC.
002 188511-6 HOUSING SET 1 SET
002 D10 INC. 14 INC. 14 0
002A 188511-6 HOUSING SET 1 SET
002A D10 INC. 14 INC. 14 0
003 865151-4 6271D NAME PLATE 1 PC.
003A 865151-4 6271D NAME PLATE 1 PC.
004 266130-9 TAPPING SCREW BIND PT 3X16 9 PC.
004A 266130-9 TAPPING SCREW BIND PT 3X16 9 PC.
005 232182-2 LEAF SPRING 1 PC.
005A 232182-2 LEAF SPRING 1 PC.
006 450584-2 F/R CHANGE LEVER 1 PC.
006A 450584-2 F/R CHANGE LEVER 1 PC.
007 650601-0 SWITCH TG563FSB-2 1 PC.
007A 650601-0 SWITCH TG563FSB-2 1 PC.
008 643909-9 BATTERY HOLDER 1 PC.
008A 643909-9 BATTERY HOLDER 1 PC.
009 251468-5 - FLAT HEAD SCREW M6X22 1 PC.
009A 251468-5 - FLAT HEAD SCREW M6X22 1 PC.
010 766002-3 KEYLESS DRILL CHUCK 10 1 PC.
010A 766002-3 KEYLESS DRILL CHUCK 10 1 PC.
011 125482-6 GEAR ASS'Y 1 PC.
011A 125482-6 GEAR ASS'Y 1 PC.
012 629817-8 DC MOTOR 1 PC.
012A 629817-8 DC MOTOR 1 PC.
013 911003-8 PAN HEAD SCREW M3X6 2 PC.
013A 911003-8 PAN HEAD SCREW M3X6 2 PC.
014 188511-6 HOUSING SET 1 SET
014 D10 INC. 2 INC. 2 0
014A 188511-6 HOUSING SET 1 SET
014A D10 INC. 2 INC. 2 0
A01 ***DC1414 DC1414 BATTERY CHARGER 1
A01A ***DC1414 DC1414 BATTERY CHARGER 1
A02 192597-4 HIGH CAPACITY BATTERY 1222 2 PC.
A02A 192597-4 HIGH CAPACITY BATTERY 1222 2 PC.
A03 414938-7 BATTERY COVER 2 PC.
A03A 414938-7 BATTERY COVER 2 PC.
A04 784636-0 +- BIT 2-65 1 PC.
A04A 784636-0 +- BIT 2-65 1 PC.
A05 824852-3 PLASTIC CARRYING CASE 1 PC.
A05A 194015-8 TOOL CHEST 1 PC.
A05B 824853-1 PLASTIC CARRYING CASE 1 PC.
A06 345261-8 HOOK PLATE 2 PC.
A07 417926-3 STRAP G0970200500 1 PC.
A08 192749-7 ML120 RECHARGEABLE FLASHLIGHT 1 PC.
A08 D10 INC. A06A07 INC. A06A07 0